9.4 JOG DIAL SECTION



JOG DIAL SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	INDB Assy	DWX3699
	2	JFLB Assy	DWX3708
	3	JOGB Assy	DWX3709
	4	Jog Panel	DAH2609
	5	Jog Plate	DAH2679
	6	Coil Spring/LD	DBH1798
	7	SW Spring	DBH1681
	8	SW Cushion HH48/2	DEC2538
	9	Cushion/RNG	DEC3466
	10	Washer	DEC3137
	11	Link Plate	DNH2848
	12	Jog B	DNK4068
	13	SW Ring	DNK5233
	14	Gear/LD	DNK6145
	15	Smoother	DNK5237
	16	Holder	DNK6556
	17	Comp Plate	DNK5243
	18	Adjust Plate	DNK5300
	19	Cam Plate	DNK5301
	20	Dial Gear	DNK5302
	21	Link Gear A	DNK5303
	22	Link Gear B	DNK5304
	23	Rack Plate	DNK5305
	24	Sheet SW	DSX1078
	25	Jog Dial A Assy	DXA2159
	26	Roller	DXB2178
	27	Stay Assy/JOG	DXB2133
	28	Encoder Spring	DBH1710
	29	Plate	DEC3700
	30	Gear/A	DNK6143
	31	Gear/B	DNK6144
	32	Leaf Spring/ADJ	DBK1376
	33	•••••	
	34	•••••	
	35	•••••	
	36	•••••	
	37	Screw (FE)	DBA1265
	38	Screw	BPZ20P100FTC
	39	Screw	BPZ30P080FNI
	40	Screw	IPZ20P060FTC